**CLASS B AIS TRANSPONDER**

# MA–500TR

# Class B AIS Transponder
# for Pleasure & Fishing Boats

Real-time Vessel Traffic Information.

# All the Advantages of AIS Transponder in an Easy to Use, Compact Design

## What is an AIS transponder?

An AIS transponder on your boat automatically receives information broadcast by other AIS-equipped vessels and base stations, all while your own vessel's static and dynamic information is being transmitted. AIS signals may reach where radar cannot, showing AIS-equipped vessels that might otherwise be hidden, such as on the other side of an island or behind a larger vessel. SOLAS commercial vessels are already required to carry a Class A AIS transponder, so your position will be known by nearby large vessels. The MA-500TR increases your safety at sea.

**SOLAS vessel**
(Class A AIS transponder)

**Other vessel, non-SOLAS**
(Class B AIS transponder)

**AIS Data**

**Base station**

**Your vessel**
(Class B AIS transponder)

## Class B AIS transponder

The MA-500TR is a Class B AIS transponder for Non-SOLAS vessels such as pleasure craft, workboat and small vessels. Your vessels information will automatically be transmitted at fixed intervals or under base station control. The MA-500TR receives dual AIS channels (Ch. 87B and Ch. 88B) simultaneously and receives both Class A and Class B AIS information.

Transmitted information by MA-500TR is
• MMSI code
• Vessel name
• Call sign
• Type of ship
• GPS antenna position
• Ship's position
• SOG (Speed over ground)
• COG (Course over ground)
• UTC date and time
• GPS antenna type
• PA (Position Accuracy)

## Simple operation

The Plotter display looks like a marine radar display. North-up, course-up and range zoom from 0.125 NM to 24 NM are supported. The Target list display shows all detected AIS equipped vessels and targets. The Danger list display shows a list of vessels that are within 6 NM CPA and 60 minutes TCPA from your vessel. The Danger list can be sorted by CPA or TCPA order. In addition to these display types, the Detail screen shows various information about the selected AIS target.

**Plotter display**

**Target list display**

Select a target vessel by using the cursor keys and then push the "ENT" button to see the Detail screens.

**Danger list display**

**Detail screens**

## CPA and TCPA for collision-risk management

When a vessel comes into the CPA and TCPA range, the vessel icon blinks on the Plotter display and emits a beep sound. When connected to external audio equipment installed on the deck or tower, the collision alarm function will alerts you even when you are away from the AIS transponder.

**On the deck**

## Individual DSC call*

When connected to a compatible Icom VHF radio, it's easy to make an individual DSC call. Select a vessel using the MA-500TR's cursor keys and then push the "DSC" button on the MA-500TR. It is not required to input an MMSI number manually.

*This function works only when connected to compatible Icom transceivers such as IC-M604A, M504A M424, M423, M400BB, M323 or M412.

## 100 Waypoints memory

Up to 100 waypoints can be stored on the waypoint list. The "MOB" button allows you to set a waypoint on your current position instantly.

## Safety-related message

When the MA-500TR receives a safety-related message from a Class A AIS transponder, the message icon appears on the Plotter display. Up to 20 received DSC messages are automatically stored in the log memory.

## 3-line NMEA input/output

The MA-500TR has 15-pin D-SUB connector providing 3-lines of NMEA input/output on the rear panel. The supplied NMEA connector cable simplifies the installation and connection to the VHF radio and other navigation equipment.

## GPS receiver comes with MA-500TR

The MXG-5000 GPS receiver is a 66 channel parallel GPS receiver with SBAS function.

## Other features

• Full dot-matrix display with adjustable backlight and contrast
• IPX7 waterproof protection (up to 1m depth of water for 30 minutes; except connectors)
• Self diagnostics function
• Flush mount installation with optional MB-75
• Slow warn function

* VHF radio is sold separately.
Above photo shows the IC-M504 (USA version).
For Europe this is the IC-M505.

**CLASS B AIS TRANSPONDER**
# MA−500TR

# MA-500TR

## SPECIFICATIONS

### GENERAL

- Operating frequencies : 161.975, 162.025 MHz
  (Ch 87B, 88B, default)
  156.025–162.025 MHz
- Type of emission : 16K0GXW (GMSK)
- Antenna impedance : 50Ω
- Usable temperature : –20°C to +60°C
  range ; –4°F to +140°F
- Power supply : 12V DC (9.6–15.6V)
  requirement
- Current drain : TX 1.5A
  (at 12.0V DC) RX 0.7A
- Dimensions (W×H×D) : 165×110×123 mm
  (projections not included) ; 6.5×4.33×4.84 in
- Weight (approx.) : 1.0kg; 2.2lb

### TRANSMITTER

- Output power : 2W
- Modulation : GMSK
- Conducted spurious : Less than –36dBm
  emission

### RECEIVER

- Sensitivity (20% error rate) : –110dBm (AIS/DSC)
- Adjacent Ch. selectivity : More than 70dB (AIS/DSC)
- Spurious response : More than 74dB (AIS)
  More than 70dB (DSC)
- Intermodulation : More than 65dB (AIS/DSC)
- Conducted spurious : Less than –57dBm (AIS)
  emission

**Measurements made in accordance with IEC 62287-1.**

All stated specifications are subject to
change without notice or obligation.

### DATA INTERFACE

- Data Input Interface :
  NMEA1, NMEA3 IEC 61162-1:2000 (4,800bps)
  or IEC 61162-2 (38,400bps)
  NMEA2 IEC 61162-2 (38,400bps)
  Sentence format RMC, GGA, VTG, GSA,
  (common to NMEA1–3) GSV, DTM, GNS, GLL,
  and GBS*[1]
  Input level (2V applied) Less than 2mA
- Data Output Interface :
  NMEA1, NMEA3 IEC 61162-1:2000 (4,800bps)
  or IEC 61162-2 (38,400bps)
  NMEA2 IEC 61162-2 (38,400bps)
  Sentence format
  NMEA1 DSC, RMC, GGA, VTG, GSA, GSV,
  GBS, DTM, DSE, GNS and GLL
  NMEA2 VDM, VDO, ALR, ACA, ACS, TXT,
  RMC*[2], GGA*[2], GNS*[2], GLL*[2], VTG*[2],
  GSA*[2], GSV*[2], GBS*[2] and DTM*[2]
  NMEA3 RMC, GGA, VTG, GSA, GSV, GBS,
  DTM, GNS, and GLL
  Output level 5V, 40mA Max.
  RS-422 balanced type
- Rating of alert terminal : 24V DC, 500mA max.

*[1] To use a third party GPS receiver with the MA-500TR,
  a GPS receiver with RAIM function is required.
*[2] Depending on AIS output setting.

**MA-500TR contents:**
(* May be sold separately, depending on country)
- AIS transponder, MA-500TR
- GPS receiver with 10m cable*
- NMEA connector cable
- Mounting bracket kits
- DC power cable

### DIMENSIONS



Unit : mm (inch)

145 (5.71)
108.4 (4.27)
123 (4.84)
110 (4.33)
165 (6.5)
31.4 (1.24)
77 (3.03)
91.4 (3.6)

### REAR PANEL VIEW



VHF antenna
GPS receiver
External alarm
MA-500TR (Rear view)
3-lines of NMEA Input/Output (NMEA 1 to 3)
Cloning cable receptacle
DC power connector
VHF transceiver, marine navigation equipment or external GPS receiver

## OPTIONS



**MB-75**

**MB-75**
FLUSH MOUNT KIT

For flush-mounting the MA-500TR to a flat surface,
such as a control panel.



* Shown with VHF radio (Sold separately).